









## TERMINAL TYPES

Batteries have specified terminals. This listing describes the various available terminals for Power-Sonic batteries:

<p><b>"F1"</b> Faston 0.187" x 0.032" Quick disconnect tabs.</p>		<p><b>"SP"</b> Spring Fully collapsible spring terminal for positive and negative contacts.</p>	
<p><b>"F2"</b> Faston 0.250" x 0.032" Quick disconnect tabs.</p>		<p><b>"U"</b> Universal Universal automotive post with nut &amp; bolt ("NB") terminal connectors</p>	
<p><b>"FP"</b> Faston Polarized Positive: "F2" Negative: "F1"</p>	<p><b>"B"</b> Button Threaded copper insert terminals</p>		
<p><b>"PC"</b> Pressure Contacts On PS-1223 battery</p>			
<p><b>"WL"</b> Insulated, stranded wire leads terminated with:</p> <ul style="list-style-type: none"> <li>• Molex Housing 5264-02 &amp; 5263-PBT plug on PS-605</li> <li>• AMP Housing 1-480318-0 &amp; 8116-1 on PS-1208</li> </ul>			
<p><b>"TS/TH"</b> Toy battery connector</p>			
<ul style="list-style-type: none"> <li>• S connector 6120TS</li> </ul>		<ul style="list-style-type: none"> <li>• H connector 6120TH</li> </ul>	