



# DELTRAN BATTERY TENDER® WP800

## Installation & Mounting Instructions



The Battery Tender® WP800 (Part # 022-0150-DL-WH) charger has an AC power cord with a NEMA 1-15 plug (2-prong, no separate ground pin) that plugs into a residential AC receptacle. The approximate AC power cord length is 6 feet. **There is no ON / OFF switch on the charger.**

The DC output cord is a 2-wire, insulated cable assembly with a black, molded, 2 pin quick-disconnect plug on the end. That plug connects to a number of DC output cable accessories.

**The common DC output cable assembly accessories are: (Approx cable lengths 18 inch min, 24 inch max.)** Shown in order from left to right:

- 081-0069-6: Fused Ring Terminal Cable Assembly
- 081-0069-4: Fused Alligator Clip Cable Assembly
- 081-0069-5: Fused Cigarette Adapter Cable Assembly



**Extension cables have the same cord configuration as the DC output cable connected to the charger body. Each end of the cable extension has a black, molded, 2 pin quick-disconnect plug.**


- 081-0148-25 Extension Cable, 25 ft long.
- 081-0148-12 Extension Cable, 12 ft long.



The following connection rule applies for DC cable assemblies and the black, molded, 2 pin quick-disconnect plug.

**If the DC cable is directly connected to the body of a charger, then the exposed pin is connected to POSITIVE voltage at the charger output.** The same will be true for the exposed pin on the end of an extension cable when the other end of the extension cable is connected to the charger DC output cable.

DC cable assembly accessories are designed so that the rings, clips, or the cigarette adapter connect to a battery. **The exposed pin on a DC cable assembly accessory is connected to NEGATIVE OR REFERENCE voltage at the battery.** Again, the same will be true for the exposed pin on the end of an extension cable when the other end of the extension cable is connected to a DC cable assembly accessory.



For inquiries and orders, contact:

MICROBATTERY.COM 7350 NW 35th Terrace, Miami, Florida 33122  
 Customer Service: 1-866-999-2355 Phone 1-305-371-9200 FAX 1-305-371-9400  
 www.microbattery.com




# DELTRAN BATTERY TENDER® WP800

## Installation & Mounting Instructions



**⚠ DANGER: NEVER CONNECT THE QUICK DISCONNECT PLUGS TOGETHER ON TWO (2) DC CABLE ASSEMBLY ACCESSORIES THAT ARE BOTH CONNECTED TO BATTERIES. THESE CABLES ARE NOT JUMPER CABLES!!**



EVEN A RELATIVELY SMALL 18 TO 22 AMP HOUR BATTERY CAN GENERATE **SEVERAL HUNDRED, MAYBE EVEN MORE THAN ONE THOUSAND AMPERES** WHEN THE TERMINALS ARE SHORT CIRCUITED!

Insulation will melt, and virtually vaporize. Conductors will turn bright orange and any combustible material that is nearby will very likely begin to burn.

**THIS SITUATION IS EXTREMELY DANGEROUS.**

*For inquiries and orders, contact:*

MICROBATTERY.COM 7350 NW 35th Terrace, Miami, Florida 33122  
Customer Service: 1-866-999-2355 Phone 1-305-371-9200 FAX 1-305-371-9400  
www.microbattery.com

Page 2 of 2